

SECTION 07112: FOAMED-IN-PLACE INSULATION

PART II - PRODUCTS

2.2 MISCELLANEOUS MATERIALS

- A. Spray Termination Angle: Plastic angle fabricated from self-extinguishing PVC.
 - 1. Jam-Ex® by EXO-TEC Manufacturing, Inc. www.exo-tec.biz
- B. Fasteners
 - 1. Screw type fasteners for wood framing
 - a. # 10 zinc plated round washer head wood screws 1 ¼" long
 - 2. Screw type fastener for light gage metal framing
 - a. # 10 zinc plated round washer head tek point screws 1 ¼" LONG
- C. Adhesive
 - 1. One part polyurethane sealant or adhesive material

PART III EXECUTION

3.3 MISCELLANEOUS MATERIALS

- A. Wood framing
 - 1. Fasten Jam-Ex® to wood framing with screw type fasteners at 12" o.c.
- B. Light gage metal framing
 - 1. Fasten Jam-Ex® to wood framing with screw type fasteners at 12" o.c.
- C. CMU, concrete and precast
 - 1. Adhere Jam-Ex by installing a continuous bed of sealant or adhesive to the Jam-Ex® and then pressing into place in its intended location.