



WINDOW ANCHOR

LOW MODULUS SILICONE SEALANT TO TIE AIR BARRIER TO THE WINDOW FRAME

WINDOW JAMB INSULATION

JAMFLASH®

- 1.) TRIM TENSION LEG TO 1" BEYOND THE EXTERIOR FACE OF THE WINDOW.
- 2.) BEND JAMFLASH® AT VEE NOTCH AT CLOSEST TO THE PLANE OF THE FACE OF THE WINDOW.
- 3.) APPLY SEALANT (OPTIONAL) TO THE BACK OF THE EXTERIOR FACE OF THE WINDOW FRAME.
- 4.) INSTALL WINDOW BY PUSHING IT OUT PAST THE EDGE OF THE JAMFLASH THEN PULLING BACK IN.

EXO-TEC MANUFACTURING, INC.
 22 WASHINGTON STREET STOUGHTON, MA 02072

(781) 344-9794 FAX (781) 344-9823
www.exo-tec.biz

JAMFLASH® DETAIL AT HOLLOW BACKED WINDOW FRAMES IN AVB WALLS