



WINDOW ANCHOR

WINDOW JAMB INSULATION

JAMFLASH®

SEALANT ADHESIVE ( OPTIONAL )

- 1.) TRIM TENSION LEG TO 1" BEYOND THE EXTERIOR FACE OF THE WINDOW.
- 2.) BEND JAMFLASH® AT VEE NOTCH AT CLOSEST TO THE PLANE OF THE FACE OF THE WINDOW.
- 3.) APPLY SEALANT ( OPTIONAL ) TO THE BACK OF THE EXTERIOR FACE OF THE WINDOW FRAME.
- 4.) INSTALL WINDOW BY PUSHING IT OUT PAST THE EDGE OF THE JAMFLASH THEN PULLING BACK IN.

**EXO-TEC MANUFACTURING, INC.**  
 22 WASHINGTON STREET STOUGHTON, MA 02072

( 781 ) 344-9794 FAX ( 781 ) 344-9823  
[www.exo-tec.biz](http://www.exo-tec.biz)

JAMFLASH® DETAIL AT HOLLOW BACKED WINDOW FRAMES